

## **1992 - 2007 FORD VAN FRONT BUMPER INSTALLATION INSTRUCTIONS**

### **Please read before beginning**

- *Stainless steel hardware may bind together when tightening—It is recommended that you apply an anti-seize assembly lubricant to the threads of each bolt before assembly*
- *This Installation requires 2 people*



### **Included Hardware:**

- |  |    |
|--|----|
| • 70036 - 1/2-13 x 1 1/2" Hex Bolt Grade 8                           | 6  |
| • 70033 - 1/2-13 Nylock Nuts SS                                      | 6  |
| • 70035 - 1/2 Washer F/W STL Zinc (.09 Thickness)                    | 12 |
| • 400511- Winch, Fairlead Cover (preinstalled w/ the below hardware) | 1  |
| ○ 70008- 1/4-20 Nylock Nuts SS                                       | 2  |
| ○ 70039- 1/4 x 7/8 Fender Washer SS                                  | 4  |
| ○ 70060- 1/4-20 x 1" Button Head Bolt SS                             | 2  |
| • 400503.4 - Keys, Tool Box Lock Set                                 |    |
| • Antiseize Packet, 2g   | 1  |

### **Installation Instructions**

1. Remove Stock Bumper.
  - a. There should be 2 bolts on each side on the backside of the Bumper holding it to the frame.
2. Attach Bumper to Mounts and Frame:
  - a. Hold bumper up in position and put bolt through the bumper and frame.
    - i. Start by putting one bolt on each side (each bolt should have a washer between both the head and the bumper and the nut and the frame).
      1. The hole on the bumper that is furthest away from the frame is the easiest one to start with.
      2. Hand tighten the nut down so the bumper can be rested on the bolt.
    - ii. Insert the other four bolts that go from inside the toolbox to the frame.
    - iii. Tighten the nuts down so that the bumper is held up but can still be moved.
3. Check that the bumper is straight from left to right and parallel to the van's grill.
4. Tighten down bolts.