

## **(Roof Rack) INSTALLATION INSTRUCTIONS** **07+ Mercedes Sprinter**

### **Please read before beginning**

- *Stainless steel hardware may bind together when tightening—It is recommended that you apply an anti-seize assembly lubricant to the threads of each bolt before assembly*
- *This installation requires two people*

### **Required tools**

- Standard wrench set
- Leveling tool



### **Included hardware:**

|                |               |
|----------------|---------------|
|                | 6 FT – 350458 |
| <b>PRE-KIT</b> | 8 FT – 350546 |
|                | SUPP – 350547 |

### **Quantity:**

- Gutter bracket with welded-in studs..... 1 per foot
- 70039 – ¼” ID x 5/8” OD Washer, Stainless Steel (.03” Thick)..... 2 per foot
- 70008 – ¼” -20 Nylock Nuts Stainless Steel..... 2 per foot
- Antiseize Packet, 2g..... 1

### **Installation Instructions**

1. Slide the “Gutter Bracket with Welded-in studs” into the tracks on the roof.
2. Lower the roof rack onto the studs and slide the roof rack into desired position
  - a. Normal Positioning: the back of the Roof rack is parallel to the rear curvature of the vehicle.
3. Once the roof rack is in place, place the washer and nylock nut onto the stud and fasten down.



**NOTE:** Depending on the size of your roof rack, we may have included extra hardware in a bag labelled “SUPPLEMENTAL KIT”. If you’ve run out of hardware and still have extra feet to bolt down, please check the original product packaging for an extra hardware kit to fasten down the remaining feet.