



SPRINTER LIGHT BAR INSTALLATION INSTRUCTIONS **07+ DODGE/MERCEDES SPRINTER**

Please read before beginning

- *Stainless steel hardware may bind together when tightening—It is recommended that you apply an anti-seize assembly lubricant to the threads of each bolt before assembly*
- *This installation requires two people*

Required tools

- Standard wrench set
- Leveling tool



Included hardware

Quantity

- Mounting hardware
 - 70124 M8-1.25x40mm Hex Head Bolt
 - 70020 5/16" ID x 3/4 OD flat washer

4
4

Installation Instructions

1. Remove the 2 bolts that hold your license plate bracket to your front bumper. This will give you access to 2 mounting holes for the sprinter
2. If you want to retain your license plate bracket measure the distance from the mounting holes on the bumper to the mounting holes where the light bar will be mounted. Use this measurement to mark and cut holes for the light bar to pass through. Once you drill the holes you can remount the license plate bracket.
3. Remove the 2 bolts that go through the top center of your bumper
4. Line up and install the 4 mounting bolts and washers that are provided into the 4 mounting locations but do not tighten.
5. Make sure your light bar is level and then completely tighten all 4 mounting bolts.
6. Your light bar has a flat spot running the entire length to mount whatever lights you would like.

